PIG Neutralising Absorbents Treatment Ratios

Treatment Ratios for:

Neutralising Mats: **MAT352** and **MAT353** Neutralising Socks: **PIG352** and **PIG353** Neutralising Pillows: **PIL352** and **PIL353**

Notice:

This report is offered as a guide and was developed from information that, to the best of New Pig Corporation's knowledge, was reliable and accurate. Due to varibales and conditions of application beyond New Pig Corporation's control, none of the data shown in this guide is to be constructed as a guarantee, expressed, or implied. New Pig Corporation assumes no responsibility, obligation, or liability in conjuction with the use or misue of the information.

Neutralisation will generate some heat and gassing off. Amounts will vary depending on the size and location of spill. Rise in temperature will be less when the surface area is larger.

The absorbent contained in the pillows and socks will absorb more liquid than the volume of the absorbent. Thus, the pillows and socks will "grow" during absorption and neutralisation.

Optimum rate of absorption will be achieved if the absorbent is spread throughout the sock and pillow. It is recommended to unroll the sock from its packaging and lay in place, keeping it as horizontal as possible. If all the absorbent goes to one end, the sock will still function but will take longer to absorb and neutralise.

The pads are most effective to catch spilled liquids, to wipe drops from dispensing utensils, and to mop up small spills.

Dispose of neutralised mixture in a suitable container and in accordance with local and country regulations.

Store in a cool, dry, and well-ventilated area. Kepp container tightly closed.

Acid Neutralisation Chart 2 lbs. of Neutraliser neutralises approximately:				
Acid	Concentration	Volume in Pints	Volume in Litres	
Sulfuric	50%	1.6	0.7557	
	10%	4.79	2.2623	
Nitric	68%	1.92	0.9068	
	40%	3.2	1.5114	
	10%	6.39	3.0180	
Acetic	100%	1.28	0.6045	
	78%	1.92	0.9068	
	40%	3.2	1.5114	
Phosphoric	40%	1.74	0.8218	
	10%	4.79	2.2623	
Hydrochloric	40%	1.92	0.9068	
	20%	3.2	1.5114	
	10%	6.39	3.0180	

PIG Treatment Ratios

Acid Neutraliser will foam during neutralising process and may give off carbon dixoide and heat when neutralising some acids.

Acid Neutraliser is NOT recommended for use on Hydrofluoric Acid.

Avoid contact with Fluorine, Lithium and 2,4,6-Trinitrotoluene. Contact with food products containing sugars may form carbon monoxide gas.

Base Neutralisation Chart 2 lbs. of Neutraliser neutralises approximately:				
Base	Concentration	Volume in Pints	Volume in Liters	
Ammonium Hydroxide	60%	2.74/1.2941	1.2941	
	42%	3.2/1.5114	1.5114	
	20%	3.83/1.8089	1.8089	
	10%	6.39/3.0180	3.0180	
Potassium Hydroxide	50%	1.83/0.8643	0.8643	
	40%	2.4/1.1335	1.1335	
	20%	5.48/2.5882	2.5882	
	10%	7.67/3.6225	3.6225	
Sodium Hydroxide	10%	9.59/4.5294	4.5294	

Avoid contact with metallic nitrates, cyanides, sulfides, and strong oxidizers. Contact with sodium or calcium hypochlorite creates chlorine gas.