



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: PLR303
Item Name	: PIG® Drive-Over DrainBlocker® Drain Cover
Contents/Package	: 1 - PIG® DrainBlocker® Drain Cover with DuPont Elvaloy® 1 - Nylon Storage Bag
Dimensions	: 91 cm x 91 cm x 1 cm
Composition	: Top: Rubber; Bottom: Urethane

Description

- Ideal for semi-permanent drain protection where liquid transfers, washdowns or other leak- and spill-prone jobs are common; eliminates the need to frequently deploy and remove a temporary cover or to permanently seal your drains
- Patented-rubber HogHyde™ Skin protects the bottom layer to ensure tight, reliable seal by standing up to puncture, tearing and abrasion, even under heavy vehicle traffic from tankers, lorries or forklifts; now 9X more puncture resistant and 5X more tear resistant!
- Flexible, tacky urethane bottom layer moulds to uneven surfaces and tightly seals drain openings to block liquid
- Also withstands UV rays, infrared light and all weather conditions; keep outdoors as long as needed without worrying about degradation; dark colour hides dirt and grime
- Leave down as preventative measure or store for emergency response; just remove protective film and put Cover over drain when a spill occurs making sure Cover overlaps drain opening at least 8cm on each edge
- Includes a nylon storage bag for easy transportation and fast spill response

Warnings & Restrictions	: NOTE: Due to the nature of softer urethane, the physical properties of these products may change over time with exposure to certain environmental conditions like temperature, humidity and UV radiation. Typical product life expectancy is 5 years. Please inspect the stored product regularly to ensure it is in a usable state.
------------------------------------	--