



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

| | |
|-------------------------|----------------------------|
| Item Number | : PLR212 |
| Item Name | : PIG® SpillBlocker® Dike |
| Contents/Package | : 1 each |
| Colour | : Yellow |
| Dimensions | : 300 cm x 5.7 cm x 3.5 cm |
| Composition | : Polyurethane |
| Weight | : 5.9 Kg |

Description

- Fast protection for when a leak is starting to spread; just surround machine with Dike to contain liquid; high-visibility yellow colour draws attention to spill for increased safety
- Exclusive New Pig formulation features a harder, tear-resistant top layer that withstands repeated use and abrasion combined with a flexible, tacky bottom layer that molds to smooth surfaces and blocks liquids from seeping underneath
- Built-in, interlocking end joints create a liquid-proof seal and allow you to join as many sections as you need without extra parts
- Confines and diverts fluids without absorbing them, making cleanup or reclamation simpler; polyurethane material resists water, oil and many chemicals
- Reusable; cleans easily with soap and water

| | |
|------------------------------------|--|
| Warnings & Restrictions | : NOTE: SPILLBLOCKER Dikes are designed for temporary use only. Pick up after each use, clean, then store properly. Do not leave down for extended periods of time. Due to the nature of softer urethane, the physical properties of these products may change over time with exposure to certain environmental conditions like temperature, humidity and UV radiation. Typical product life expectancy is 5 years. Please inspect the stored product regularly to ensure it is in a usable state. |
|------------------------------------|--|