



**Tel:** +31 (0)76 596 9250  
**Email:** pigpost@newpig.com

# PRODUCT DATA SHEET

<b>Item Number</b>	: MAT462
<b>Item Name</b>	: PIG® White Oil-Only Mat Roll
<b>Liquids Absorbed</b>	: Oil-Only
<b>Contents/Package</b>	: 1 roll
<b>Colour</b>	: White
<b>Dimensions</b>	: 76 cm x 46 m
<b>Composition</b>	: 100% Polypropylene
<b>Absorbency</b>	: 76.2 L/Bag
<b>Weight</b>	: 6.8 Kg

## Description

- Layers of 100% polypropylene are thermally bonded to make PIG Mat the strongest mat on the market; won't rip, tear or fray even when saturated
- Exclusive dimple pattern speeds wicking of liquid throughout mat for faster, easier cleanup
- Highly absorbent, fine-fibre construction won't leave behind liquids or fibre residue
- Absorbs and retains oils and oil-based liquids - including lubricants and fuels - without taking in a drop of water
- Light-weight construction is economical for small tasks and cleanups