



**Tel:** +31 (0)76 596 9250  
**Email:** pigpost@newpig.com

# PRODUCT DATA SHEET

<b>Item Number</b>	: PLR230
<b>Item Name</b>	: PIG® SPILLBLOCKER® Rough Surface Dike
<b>Contents/Package</b>	: 1 - Connector, 1 - Yellow Disposal Bag
<b>Colour</b>	: Yellow
<b>Dimensions</b>	: 300 cm x 5.1 cm x 5.7 cm
<b>Composition</b>	: Polyurethane
<b>Weight</b>	: 5.6 Kg

## Description

- Exclusive New Pig formulation features a tear-resistant top layer with a super-tacky bottom layer that seals tight by adhering and conforming to most rough surfaces and blocks liquids
- Fast protection for when a spill is heading right for your drain on a rough surface; just set dike down with sticky side away from surface, turn dike over and press into place
- Confines and diverts fluids without absorbing them, making cleanup or reclamation simpler
- Polyurethane material resists water, oils and many chemicals
- Intended for one-time use only; ideal for containing hazardous or other liquids on rough surfaces

<b>Warnings &amp; Restrictions</b>	: NOTE: Due to the nature of softer urethane, the physical properties of these products may change over time with exposure to certain environmental conditions like temperature, humidity and UV radiation. Typical life expectancy is 5 years. Please inspect the stored product regularly to ensure it is in a usable state.
------------------------------------	--