



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: KIT302
Item Name	: PIG® HAZ-MAT Spill Kit in a 360-litre Overpack Drum
Liquids Absorbed	: Acids, Caustics & Unknowns
Contents/Package	: 2 - 13cm x 3m Dikes 6 - 8cm x 3m Socks 12 - 8cm x 117cm Socks 75 - 38cm x 51cm Mat Heavy-weight Pads 7 - 41cm x 43cm Pillows 10 - 91cm x 152cm Temporary Disposal Bags & Ties 6 - 15cm x 5.5cm Tamperproof Labels 1 - 80cm Dia x 105.5cm H 360-Litre Overpack
Colour	: Pink
Dimensions	: ext. dia. 80cm x 105cm H
Composition	: Socks, Mats, Pillows & Dikes - Polypropylene Skin & Filler Container - Polyethylene
Absorbency	: 237 L/Kit
Weight	: 53.9 Kg

Description

- Overpack drum container is UN-rated for Packing Groups I, II and III (UN1H2/X295/S), so it's ideal for regulated packaging applications, including shipping hazardous waste by land, sea or rail
- Lift-out, prepacked baskets speed access and guard contents from UV
- PIG HazMat Socks stop spreading spills; PIG HazMat Pads and Pillows absorb quickly
- PIG HazMat Absorbents are specially treated for unsurpassed performance with concentrated corrosives, such as 98% sulfuric acid and 30% sodium hydroxide
- Lightweight, 100% polyethylene container resists chemicals and keeps contents clean and dry

Warnings & Restrictions	: ATTENTION: Independent testing indicates that PIG HAZ-MAT products are compatible with and absorb most acids and caustics. Due to variables and conditions of applications beyond our control, New Pig cannot guarantee that this product will absorb to your satisfaction. To insure effectiveness and your safety, we recommend that you conduct compatibility and absorption testing of your chemicals with PIG HAZ-MAT products prior to purchase. If you have any questions or need samples to test, please call your local distributor.
------------------------------------	--