



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: P45-1
Item Name	: PIG® Crysta-lite Absorbent Granules
Liquids Absorbed	: Oil, Coolants, Solvents, Water & Most Chemicals
Contents/Package	: 1 bag
Colour	: White
Composition	: Silicon, Aluminium, Iron, Sodium, Potassium, Calcium, Magnesium & Others
Absorbency	: 18 L/Bag
Weight	: 3.5 Kg

Description

- An economical, light weight, non-combustible loose absorbent for spillages of water, oils, organic solvents, and most acids. PIG® Crysta-lite Absorbent will absorb many times its own weight
- Can be used as an absorbent media in enclosed containers for the disposal of liquid toxic waste substances
- No leak zones! Consistent construction produces a mat that is free of light spots to absorb liquid evenly for better wicking and retention
- Material is quarried, crushed, processed and screened to create a particle size of 3.0mm to 6.0mm
- The "expansion" of the product generates countless tiny air bubbles within the structure creating the ultra light weight of PIG® Crysta-lite Absorbent
- High surface area and excellent, fast-absorption properties give Absorbent the ability to create a low-slip surface.

Warnings & Restrictions : Packaged by volume; seasonal variance can affect packaged weight.