



**Tel:** +31 (0)76 596 9250  
**Email:** pigpost@newpig.com

# PRODUCT DATA SHEET

<b>Item Number</b>	: MAT242
<b>Item Name</b>	: PIG® Rip-&-Fit® Universal Mat
<b>Liquids Absorbed</b>	: Oil, Coolants, Solvents & Water
<b>Contents/Package</b>	: 1 roll/dispenser box
<b>Colour</b>	: Grey
<b>Dimensions</b>	: 38 cm x 18 m
<b>Composition</b>	: 100% Polypropylene
<b>Absorbency</b>	: 29.7 L/Dispenser
<b>Weight</b>	: 3.18 Kg

## Description

- Extra perforations in our Rip-&-Fit Mat allow you to easily "rip" this PIG Mat and "fit" it to your application without cutting
- No matter how you rip it, this mat features the proven eight-layer, 100% polypropylene construction of PIG Mat, the strongest mat on the market
- Exclusive dimple pattern speeds wicking of liquid throughout mat for faster, easier cleanup
- Dispenser box makes it easy to take, carry and store your mat while protecting it from dirt and moisture
- Heavy-weight construction delivers greater durability and absorbency for demanding tasks and large-volume cleanups

<b>Recycled Content</b>	: 25% or more Recycled Content
-------------------------	--------------------------------