



**Tel:** +31 (0)76 596 9250  
**Email:** pigpost@newpig.com

# PRODUCT DATA SHEET

<b>Item Number</b>	: DRM1127
<b>Item Name</b>	: PIG® Burpless® One-Hand-Sealable Steel Drum Funnel with Overfill Preventer
<b>Contents/Package</b>	: 1 each
<b>Colour</b>	: Black, Red or Yellow
<b>Dimensions</b>	: 29cm W x 38cm L x 38cm H
<b>Composition</b>	: Funnel: 18-Gauge Steel; Lid Gasket: 70 Dura Nitrile "87"; Bung Gasket: PTFE

## Description

- Patented Burpless design vents during pouring for fast, smooth flow with no dangerous splashback
- Exclusive latching handle design easily opens and closes lid in a simple, single-handed operation
- Lets you pour without venting through 3/4" bung, a possible closed container reg violation if left open
- Nitrile gasket and locking mechanism completely seal lid to help reduce vapour emissions
- Lockable to prevent unauthorised access

**Certifications & Approvals** : FM Approved when used with Flame Arrestor.