



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: GRP001
Item Name	: Utility Board for Adhesive-Backed Grippy® Mat
Contents/Package	: 1 each
Colour	: White
Dimensions	: 97cm W x 15cm D
Composition	: HDPE
Weight	: 1 Kg

Description

- Use the same cutting guide that we use to install Grippy Mat in retail, grocery and commercial environments - it's fast, easy and professional
- Convenient, pre-scored "template" guides your blade, producing clean, accurate cuts
- Create perfect corners and 45° angles for working around obstacles or making shapes
- Can also be used as a float to smooth out Grippy Mat
- Connect 2 boards together for cutting or installing mats wider than 91cm or making diagonal cuts
- Designed to use with our Safety Knife for Grippy® Mat (GRP012, sold separately)