



**Tel:** +31 (0)76 596 9250  
**Email:** pigpost@newpig.com

# PRODUCT DATA SHEET

<b>Item Number</b>	: FLT900
<b>Item Name</b>	: PIG® Outdoor Filter Berm Pad
<b>Contents/Package</b>	: 1 each
<b>Colour</b>	: Black & Yellow
<b>Dimensions</b>	: 49.5cm W x 68.5cm L x 5cm H
<b>Composition</b>	: Berm - Vinyl, Polyurethane Foam, Brass; Absorbent - Polyester, Cotton and Vinyl
<b>Absorbency</b>	: 2.8 L
<b>Weight</b>	: 3.5 Kg

## Description

- Replaceable absorbents line berm walls to capture leaks and spills of oils and fuels; clean water passes through walls as hydrocarbons are filtered out
- 5cm foam sidewalls provide structure and increase sump capacity in the event of large rainfalls (ensures adequate filtering time)
- Berm Pad is lightweight for easy handling yet durable enough to hold heavy loads
- Folds down and straps shut for quick storage and grab-and-go transportation
- Corner grommets let you stake Berm Pad to the ground to help stay in place when empty
- Ideal for temporary storage of small generators and other small equipment or containers at construction sites, oil fields and other outdoor areas